
Meridian 1

ISDN Basic Rate Interface

Installation

Document Number: 553-3901-200
Document Release: Standard 5.00
Date: October 1997

© 1992, 1997
All rights reserved

Printed in Canada

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

October 1997

Issue 5.00 released as Standard for Generic X11 Release 23.

August 1996

Issue 4.00 released as Standard for Generic X11 Release 22.0x.

December 1995

Issue 3.00 released as Standard for Generic X11 Release 21.1x.

Note: No issue 2.00 was published.

December 1994

Issue 1.00 released as Standard for Generic X11 Release 20.

July 1994

Standard version released for Generic X11 Release 19.

July 1993

Standard version released for Generic X11 Release 18.

Contents

About this guide	1
Applicability of this guide	1
How this guide is organized	1
Related documents	2
 Preinstallation preparation	 3
Preparing the site	3
Unpacking and inspection	4
Taking inventory	4
 Installing ISDN BRI hardware for line and trunk applications	 5
Installing ISDN BRI hardware for line applications	5
Installation procedures	5
Selecting the card slots	6
Removing the module cover for card installation	15
Installing the MISP	16
Installing the BRSC, SILC and UILC	17
Connecting ISDN BRI terminals to Meridian 1	18
Installing ISDN BRI hardware for trunk applications	40
Installation procedures	40
Selecting the card slots	40
Removing the module cover for card installation	40
Installing the MISP	40
Installing clock referencing on the SILC	41
Installing the SILC and the UILC	45

Connecting Meridian 1 to the Main Distribution Frame (MDF) ..	45
Cross-connecting the Main Distribution Frame (MDF)	45
Card location forms	47